

All models

Assembly, first ride, charging, cleaning and what to check every month.

1. What is in the crate

The bike ships with the front wheel, handlebar and pedals removed. Everything that needs a torque wrench is already done and marked with a witness line.

2. Assembly

Front wheel	thru-axle, 12 Nm
Handlebar clamp	4 bolts, 5 Nm, crosswise
Pedals	left pedal is reverse thread
Stem bolts	5 Nm - do not exceed

Any AUMBIKE workshop will assemble and safety-check the bike for free.

3. Before the first ride

Charge the pack fully once. Check both brakes bite before the lever reaches the bar. Check the front axle is fully seated. Set saddle height so your leg is almost straight at the bottom of the pedal stroke.

4. Charging

Never charge a wet charge port. Wipe it and wait ten minutes. This is the single most common cause of electrical faults we see in the wet season.

For storage over a week, leave the pack at 50 to 70 per cent, indoors.

5. Wading depth

Standing water up to the bottom bracket is fine. Above the crank, get off and push - water forced past the motor bearing seals will shorten their life.

6. Monthly check

Brake pads	replace under 1 mm of material
Tyre pressure	see sidewall; drop 10% in the wet
Chain	clean and lube; replace at 0.75% stretch
Bolts	stem, bars, rack, kickstand

Bring the bike in once a year for a controller check and firmware update.

Both are free for the life of the bike.

AUMBIKE - Lot 12, Jalan Kemajuan, Seksyen 13, 46200 Petaling Jaya, Malaysia
Sample document supplied with this website template. Replace before you go live.